



Figure A7. 1994 Uniform Building Code zone map. Zones are identified by the numbers from 0 to 4. Seismic zone factors are assigned to each zone; **Zone 0 = 0**, **Zone 1 = 0.075**, **Zone 2A = 0.15**, **Zone 2B = 0.20**, **Zone 3 = 0.3**, and **Zone 4 = 0.4**. Each zone also has specific structural detailing requirements. After ICBO, 1994 (This map was redrawn from the original source, if differences occur, the original source should be used).